

TROFAZNI ULAZNI EMI FILTERI

| Model | Struja | Crtež | L | L1 | W | W1 | H |
|----------------------|---------------|--------------|----------|-----------|----------|-----------|----------|
| SKS1.5KI/5A (1,5KW) | 5A | Sl.1 | 99 | 50 | 105 | 95 | 40 |
| SKS3.7KI/8A (3,7KW) | 8A | Sl.1 | 99 | 50 | 105 | 95 | 40 |
| SKS7.5KI/16A (7,5KW) | 16A | Sl.2 | 185 | 168 | 108 | 85 | 60 |
| SKS15KI/30A (15KW) | 30A | Sl.2 | 185 | 168 | 108 | 85 | 60 |
| SKS22KI/45A (22KW) | 45A | Sl.2 | 185 | 168 | 108 | 85 | 60 |
| SKS37KI/80A (37KW) | 80A | Sl.3 | 310 | 280 | 168 | 142 | 107 |

SL.1**SL.2****SL.3**